



# Original Instruction Manual

Article no.: 10871871

Version 05/2017

## Brakte Piston Wind-Back Tool, 35-part



### Scope of Delivery

- 2x Rotating spindle (turning clockwise and counterclockwise)
- 2x Hexagon socket wrench
- 4x Retainer plate
- 2x Pin punch
- 1x Bottle of lubricant
- 24x Adapter
  
- 1x Plastic case

**ATP Auto-Teile-Pöllath Handels GmbH**  
Schulgässchen 2  
91281 Kirchenthumbach  
Germany  
[www.atp-autoteile.de](http://www.atp-autoteile.de)

All company and product names in this instruction manual are trademarks of the respective owners. All rights reserved.

## **General Safety Instructions**

Before commissioning, please read the manual carefully and store it afterwards. If you pass the device on to somebody else, please also pass on the manual. The manufacturer cannot be held liable for damage to persons or property caused by improper use or improper operation. In addition, the warranty and guarantee also expire in such cases.

# **1. General Information**

This device has been purpose-designed. We explicitly stress that this device must not be altered and/or used in a way that is contrary to its originally intended purpose.

Changes which serve the purpose of technical progress can be made without notice by the manufacturer and may not be considered in the manual yet.

# **2. Safety Instructions**

**Please follow the instructions below to avoid malfunctions, damage and health impairments:**

- Besides the safety instructions mentioned in the manual, it is mandatory to use the device in compliance with the regulations regarding safety, accident prevention and environmental protection, which are universally valid for the application area of this device.
- This brake piston wind-back tool is not intended for use by persons with reduced physical, sensory or mental capabilities, unless they have been given supervision or instruction concerning use of the device by a person responsible for their safety.
- Keep unauthorised persons/children away from the work area.
- Never operate this device when you are tired or under the influence of drugs, medication or alcohol.
- The use and repair of this device requires special expertise and/or corresponding training.
- Please store packaging material (such as packaging film, plastic bags, polystyrene, etc.) exclusively out of reach of children, especially infants - packaging material often bears indistinguishable dangers (e.g. choking hazard).

## **Intended Use**

- The brake piston wind-back tool has not been designed for commercial use.
- It is vital to check the device for functionality before each use. The device must not be used if proper function is not given or if damage of any kind has been detected.

## **Storing/Maintenance**

The device must be stored as follows:

- Do not store outdoors! The brake piston wind-back tool is to be stored in a dry and dust-free environment, preferably slightly lubricated.
- Do not expose the device to fluids and/or aggressive substances
- Store the device out of the reach of children.

### 3. Usage

1. Take the adapter which is suitable for your vehicle.  
The guide noses of the adapter must fit into the depressions in the brake piston.

The adapters 0, 8, and 9 have an edge which must fit over the brake piston.



2. In order to put the retainer plate onto the spindle nut, push the sliding handle aside.



3. Position the brake piston wind-back tool between the brake piston and the caliper frame.



4. Tighten the brake piston wind-back tool between the brake piston and the caliper frame by turning the spindle clockwise or the spindle nut counterclockwise.



- Turning the spindle causes the brake piston to wind back.



- By turning the nut clockwise or the spindle counterclockwise, the brake piston wind-back tool loosens and you can remove it. Please note: Owing to its hexagonal shape, the spindle nut can be tightened e.g. with an open-end spanner.



**Steps 4-6 are only applicable to clockwise-turning spindles.**  
**If you own a brake piston which turns counterclockwise, please turn the spindle or the nut in the opposite direction.**

## 4. Application



Adapter	Description
O	Retainer plate
0	Retainer plate
11	Retainer plate
12	Retainer plate
0	General Motors
2	Citroen XM, Xantia and others
3	Alfa Romeo, Audi, Austin, BMW, Ford, Honda, Jaguar, Mercedes-Benz, Mitsubishi, Nissan, Rover, Toyota, VW
4	Alfa Romeo 164 2.0, Ford, Mazda, Saab 9000, Subaru
5	Adapter square drive with 3/8 inch
6	Nissan Primera, VW-Golf MK 4
7	Audi 80;90; V8 + 100, Ford Sierra ABS + Scorpio from 1985 onwards, Honda Prelude, Nissan Silvia 1.8 turbo, Rover 8000, Saab 9000, Subaru L+Z, VW Golf + Passat
8	General Motors
9	General Motors
A	Renault
B	Ford, Lincoln, Subaru
C	Mini, Nissan, Opel Vauxhall, Toyota
D	Renault, Citroen
E	Nissan
F	Opel Vauxhall, Fiat
G	Peugeot
J	Alfa Romeo, Audi, Fiat, Ford, Honda, Jaguar, Lancia, Nissan, Peugeot, Renault, Rover, Saab, Seat, Subaru, Volvo, VW
K	Citroen C5
K1	Citroen
K2	Citroen
M	Ford, Mini, Nissan
N	Alfa Romeo, Audi, Ford, Honda, Saab, VW
P	Audi, BMW, Citroen, Ford, Lancia, Proton, Renault, Rover, VW
Z	Ford, Mazda, Mitsubishi, Toyota

## 5. Disposal

Please dispose of the product at the end of its service life in accordance with the applicable legal provisions. The same applies to the packaging material.

In this way, you actively contribute to environmental protection.

No liability for printing errors. This document is subject to change without prior notice.

©Copyright  
ATP Auto-Teile-Pöllath Handels GmbH  
Schulgässchen 2  
91281 Kirchenthumbach  
Germany  
Tel. +49(0)9647 – 92903-0 / Fax. +49(0)96 47 – 92903-9399  
Email: [info@atp-autoteile.de](mailto:info@atp-autoteile.de)  
[www.atp-autoteile.de](http://www.atp-autoteile.de)